APPLICATIONS

BUICK
- ALLURE 2005-09
- CENTURY 2004-05
- LACROSSE 2005-09
- RAINIER 2004-07
- RENDEZVOUS 2002-07
- TERRAZA 2005-08

CHEVROLET
- AVALANCHE 2003-06
- CAVALIER 2000-05
- COLORADO 2004-10
- EXPRESS 2003-07
- IMPALA 2000-05
- MALIBU 2001-03
- MALIBU CLASSIC 2004-05
- MONTE CARLO 2000-05
- SILVERADO PICKUP CLASSIC 2007
- SILVERADO PICKUP (All Models) 2003-06
- SSR 2003-06
- SUBURBAN 2003-06
- TAHOE 2003-2006
- TRAILBLAZER 2002-09
- UPLANDER 2005-08
- VENTURE VAN 2000-05

GMC
- CANYON 2004-10
- ENVOY 2002-09
- SAVANNA FULL SIZE VAN 2003-07
- SIERRA CLASSIC 2007
- SIERRA 2003-2006
- YUKON/ YUKON XL 2003-06

HUMMER
- H3 2006-09

ISUZU
- ASCENDER 2003-08
- I SERIES PICKUPS 2006-08

OLDSMOBILE
- ALERO 2001-04
- BRAVADA 2002-05
- INTRIGUE 2002
- SILHOUETTE 2000-04

PONTIAC
- AZTEC 2001-05
- * GRAND AM 2001-05
- GRAND PRIX 2004-08
- MONTANA SV6 (CANADA) 2005-08
- MONTANA 2000-05
- SUNFIRE 2000-05

SAAB
- 9-7X 2005-09

SATURN
- RELAY 2005-07

APPLICATIONS

BUICK
- ALLURE 2005-09
- CENTURY 2004-05
- LACROSSE 2005-09
- RAINIER 2004-07
- RENDEZVOUS 2002-07
- TERRAZA 2005-08

CHEVROLET
- AVALANCHE 2003-06
- CAVALIER 2000-05
- COLORADO 2004-10
- EXPRESS 2003-07
- IMPALA 2000-05
- MALIBU 2001-03
- MALIBU CLASSIC 2004-05
- MONTE CARLO 2000-05
- SILVERADO PICKUP CLASSIC 2007
- SILVERADO PICKUP (All Models) 2003-06
- SSR 2003-06
- SUBURBAN 2003-06
- TAHOE 2003-2006
- TRAILBLAZER 2002-09
- UPLANDER 2005-08
- VENTURE VAN 2000-05

GMC
- CANYON 2004-10
- ENVOY 2002-09
- SAVANNA FULL SIZE VAN 2003-07
- SIERRA CLASSIC 2007
- SIERRA 2003-2006
- YUKON/ YUKON XL 2003-06

HUMMER
- H3 2006-09

ISUZU
- ASCENDER 2003-08
- I SERIES PICKUPS 2006-08

OLDSMOBILE
- ALERO 2001-04
- BRAVADA 2002-05
- INTRIGUE 2002
- SILHOUETTE 2000-04

PONTIAC
- AZTEC 2001-05
- * GRAND AM 2001-05
- GRAND PRIX 2004-08
- MONTANA SV6 (CANADA) 2005-08
- MONTANA 2000-05
- SUNFIRE 2000-05

SAAB
- 9-7X 2005-09

SATURN
- RELAY 2005-07

APPLICATIONS

BUICK
- ALLURE 2005-09
- CENTURY 2004-05
- LACROSSE 2005-09
- RAINIER 2004-07
- RENDEZVOUS 2002-07
- TERRAZA 2005-08

CHEVROLET
- AVALANCHE 2003-06
- CAVALIER 2000-05
- COLORADO 2004-10
- EXPRESS 2003-07
- IMPALA 2000-05
- MALIBU 2001-03
- MALIBU CLASSIC 2004-05
- MONTE CARLO 2000-05
- SILVERADO PICKUP CLASSIC 2007
- SILVERADO PICKUP (All Models) 2003-06
- SSR 2003-06
- SUBURBAN 2003-06
- TAHOE 2003-2006
- TRAILBLAZER 2002-09
- UPLANDER 2005-08
- VENTURE VAN 2000-05

GMC
- CANYON 2004-10
- ENVOY 2002-09
- SAVANNA FULL SIZE VAN 2003-07
- SIERRA CLASSIC 2007
- SIERRA 2003-2006
- YUKON/ YUKON XL 2003-06

HUMMER
- H3 2006-09

ISUZU
- ASCENDER 2003-08
- I SERIES PICKUPS 2006-08

OLDSMOBILE
- ALERO 2001-04
- BRAVADA 2002-05
- INTRIGUE 2002
- SILHOUETTE 2000-04

PONTIAC
- AZTEC 2001-05
- * GRAND AM 2001-05
- GRAND PRIX 2004-08
- MONTANA SV6 (CANADA) 2005-08
- MONTANA 2000-05
- SUNFIRE 2000-05

SAAB
- 9-7X 2005-09

SATURN
- RELAY 2005-07

APPLICATIONS

BUICK
- ALLURE 2005-09
- CENTURY 2004-05
- LACROSSE 2005-09
- RAINIER 2004-07
- RENDEZVOUS 2002-07
- TERRAZA 2005-08

CHEVROLET
- AVALANCHE 2003-06
- CAVALIER 2000-05
- COLORADO 2004-10
- EXPRESS 2003-07
- IMPALA 2000-05
- MALIBU 2001-03
- MALIBU CLASSIC 2004-05
- MONTE CARLO 2000-05
- SILVERADO PICKUP CLASSIC 2007
- SILVERADO PICKUP (All Models) 2003-06
- SSR 2003-06
- SUBURBAN 2003-06
- TAHOE 2003-2006
- TRAILBLAZER 2002-09
- UPLANDER 2005-08
- VENTURE VAN 2000-05

GMC
- CANYON 2004-10
- ENVOY 2002-09
- SAVANNA FULL SIZE VAN 2003-07
- SIERRA CLASSIC 2007
- SIERRA 2003-2006
- YUKON/ YUKON XL 2003-06

HUMMER
- H3 2006-09

ISUZU
- ASCENDER 2003-08
- I SERIES PICKUPS 2006-08

OLDSMOBILE
- ALERO 2001-04
- BRAVADA 2002-05
- INTRIGUE 2002
- SILHOUETTE 2000-04

PONTIAC
- AZTEC 2001-05
- * GRAND AM 2001-05
- GRAND PRIX 2004-08
- MONTANA SV6 (CANADA) 2005-08
- MONTANA 2000-05
- SUNFIRE 2000-05

SAAB
- 9-7X 2005-09

SATURN
- RELAY 2005-07

APPLICATIONS

BUICK
- ALLURE 2005-09
- CENTURY 2004-05
- LACROSSE 2005-09
- RAINIER 2004-07
- RENDEZVOUS 2002-07
- TERRAZA 2005-08

CHEVROLET
- AVALANCHE 2003-06
- CAVALIER 2000-05
- COLORADO 2004-10
- EXPRESS 2003-07
- IMPALA 2000-05
- MALIBU 2001-03
- MALIBU CLASSIC 2004-05
- MONTE CARLO 2000-05
- SILVERADO PICKUP CLASSIC 2007
- SILVERADO PICKUP (All Models) 2003-06
- SSR 2003-06
- SUBURBAN 2003-06
- TAHOE 2003-2006
- TRAILBLAZER 2002-09
- UPLANDER 2005-08
- VENTURE VAN 2000-05

GMC
- CANYON 2004-10
- ENVOY 2002-09
- SAVANNA FULL SIZE VAN 2003-07
- SIERRA CLASSIC 2007
- SIERRA 2003-2006
- YUKON/ YUKON XL 2003-06

HUMMER
- H3 2006-09

ISUZU
- ASCENDER 2003-08
- I SERIES PICKUPS 2006-08

OLDSMOBILE
- ALERO 2001-04
- BRAVADA 2002-05
- INTRIGUE 2002
- SILHOUETTE 2000-04

PONTIAC
- AZTEC 2001-05
- * GRAND AM 2001-05
- GRAND PRIX 2004-08
- MONTANA SV6 (CANADA) 2005-08
- MONTANA 2000-05
- SUNFIRE 2000-05

SAAB
- 9-7X 2005-09

SATURN
- RELAY 2005-07

APPLICATIONS

BUICK
- ALLURE 2005-09
- CENTURY 2004-05
- LACROSSE 2005-09
- RAINIER 2004-07
- RENDEZVOUS 2002-07
- TERRAZA 2005-08

CHEVROLET
- AVALANCHE 2003-06
- CAVALIER 2000-05
- COLORADO 2004-10
- EXPRESS 2003-07
- IMPALA 2000-05
- MALIBU 2001-03
- MALIBU CLASSIC 2004-05
- MONTE CARLO 2000-05
- SILVERADO PICKUP CLASSIC 2007
- SILVERADO PICKUP (All Models) 2003-06
- SSR 2003-06
- SUBURBAN 2003-06
- TAHOE 2003-2006
- TRAILBLAZER 2002-09
- UPLANDER 2005-08
- VENTURE VAN 2000-05

GMC
- CANYON 2004-10
- ENVOY 2002-09
- SAVANNA FULL SIZE VAN 2003-07
- SIERRA CLASSIC 2007
- SIERRA 2003-2006
- YUKON/ YUKON XL 2003-06

HUMMER
- H3 2006-09

ISUZU
- ASCENDER 2003-08
- I SERIES PICKUPS 2006-08

OLDSMOBILE
- ALERO 2001-04
- BRAVADA 2002-05
- INTRIGUE 2002
- SILHOUETTE 2000-04

PONTIAC
- AZTEC 2001-05
- * GRAND AM 2001-05
- GRAND PRIX 2004-08
- MONTANA SV6 (CANADA) 2005-08
- MONTANA 2000-05
- SUNFIRE 2000-05

SAAB
- 9-7X 2005-09

SATURN
- RELAY 2005-07

XSVI-2003
INSTALLATION INSTRUCTIONS

In the GM vehicles listed below there are no 12 volt accessory wires currently in the factory harness making the installer run an accessory wire to the fuse box or underneath the steering column when installing an aftermarket radio. The XSVI-2003 is designed to provide a 12 volt 10 amp switched accessory output along with the rest of the wires needed to install an aftermarket radio. The R.A.P. (Retained Accessory Power) function, where power is supplied to the radio after the ignition is shut off until one of the front doors are opened, is retained by the XSVI-2003.

NOTE: The XSVI-2003 does not retain the factory warning chimes that are provided by the factory radio, Onstar, or the factory amplifier if so equipped.

Wiring the XSVI-2003:

Wiring up the XSVI-2003 is like wiring up any other wire harness that would attach to the aftermarket radios harness. The Metra/EIA wire code can be found on the back of this package that will aid you in the wiring of your aftermarket radio.

INITIALIZE THE XSVI INTERFACE BEFORE TURNING ON RADIO:

With all connections made and harnesses connected to the vehicle, turn ignition key to the ON position for thirty seconds, then turn key off.

(See Applications on back of page)

REV. 03/10/10 INSTXSVI-2003
1-800-221-0932 www.metraonline.com
METRA ELECTRONICS CORPORATION © COPYRIGHT 2010

XSVI-2003
INSTALLATION INSTRUCTIONS

In the GM vehicles listed below there are no 12 volt accessory wires currently in the factory harness making the installer run an accessory wire to the fuse box or underneath the steering column when installing an aftermarket radio. The XSVI-2003 is designed to provide a 12 volt 10 amp switched accessory output along with the rest of the wires needed to install an aftermarket radio. The R.A.P. (Retained Accessory Power) function, where power is supplied to the radio after the ignition is shut off until one of the front doors are opened, is retained by the XSVI-2003.

NOTE: The XSVI-2003 does not retain the factory warning chimes that are provided by the factory radio, Onstar, or the factory amplifier if so equipped.

Wiring the XSVI-2003:

Wiring up the XSVI-2003 is like wiring up any other wire harness that would attach to the aftermarket radios harness. The Metra/EIA wire code can be found on the back of this package that will aid you in the wiring of your aftermarket radio.

INITIALIZE THE XSVI INTERFACE BEFORE TURNING ON RADIO:

With all connections made and harnesses connected to the vehicle, turn ignition key to the ON position for thirty seconds, then turn key off.

(See Applications on back of page)

REV. 03/10/10 INSTXSVI-2003
1-800-221-0932 www.metraonline.com
METRA ELECTRONICS CORPORATION © COPYRIGHT 2010

XSVI-2003
INSTALLATION INSTRUCTIONS

In the GM vehicles listed below there are no 12 volt accessory wires currently in the factory harness making the installer run an accessory wire to the fuse box or underneath the steering column when installing an aftermarket radio. The XSVI-2003 is designed to provide a 12 volt 10 amp switched accessory output along with the rest of the wires needed to install an aftermarket radio. The R.A.P. (Retained Accessory Power) function, where power is supplied to the radio after the ignition is shut off until one of the front doors are opened, is retained by the XSVI-2003.

NOTE: The XSVI-2003 does not retain the factory warning chimes that are provided by the factory radio, Onstar, or the factory amplifier if so equipped.

Wiring the XSVI-2003:

Wiring up the XSVI-2003 is like wiring up any other wire harness that would attach to the aftermarket radios harness. The Metra/EIA wire code can be found on the back of this package that will aid you in the wiring of your aftermarket radio.

INITIALIZE THE XSVI INTERFACE BEFORE TURNING ON RADIO:

With all connections made and harnesses connected to the vehicle, turn ignition key to the ON position for thirty seconds, then turn key off.

(See Applications on back of page)

REV. 03/10/10 INSTXSVI-2003
1-800-221-0932 www.metraonline.com
METRA ELECTRONICS CORPORATION © COPYRIGHT 2010

XSVI-2003
INSTALLATION INSTRUCTIONS

In the GM vehicles listed below there are no 12 volt accessory wires currently in the factory harness making the installer run an accessory wire to the fuse box or underneath the steering column when installing an aftermarket radio. The XSVI-2003 is designed to provide a 12 volt 10 amp switched accessory output along with the rest of the wires needed to install an aftermarket radio. The R.A.P. (Retained Accessory Power) function, where power is supplied to the radio after the ignition is shut off until one of the front doors are opened, is retained by the XSVI-2003.

NOTE: The XSVI-2003 does not retain the factory warning chimes that are provided by the factory radio, Onstar, or the factory amplifier if so equipped.

Wiring the XSVI-2003:

Wiring up the XSVI-2003 is like wiring up any other wire harness that would attach to the aftermarket radios harness. The Metra/EIA wire code can be found on the back of this package that will aid you in the wiring of your aftermarket radio.

INITIALIZE THE XSVI INTERFACE BEFORE TURNING ON RADIO:

With all connections made and harnesses connected to the vehicle, turn ignition key to the ON position for thirty seconds, then turn key off.

(See Applications on back of page)

REV. 03/10/10 INSTXSVI-2003
1-800-221-0932 www.metraonline.com
METRA ELECTRONICS CORPORATION © COPYRIGHT 2010

XSVI-2003
INSTALLATION INSTRUCTIONS

In the GM vehicles listed below there are no 12 volt accessory wires currently in the factory harness making the installer run an accessory wire to the fuse box or underneath the steering column when installing an aftermarket radio. The XSVI-2003 is designed to provide a 12 volt 10 amp switched accessory output along with the rest of the wires needed to install an aftermarket radio. The R.A.P. (Retained Accessory Power) function, where power is supplied to the radio after the ignition is shut off until one of the front doors are opened, is retained by the XSVI-2003.

NOTE: The XSVI-2003 does not retain the factory warning chimes that are provided by the factory radio, Onstar, or the factory amplifier if so equipped.

Wiring the XSVI-2003:

Wiring up the XSVI-2003 is like wiring up any other wire harness that would attach to the aftermarket radios harness. The Metra/EIA wire code can be found on the back of this package that will aid you in the wiring of your aftermarket radio.

INITIALIZE THE XSVI INTERFACE BEFORE TURNING ON RADIO:

With all connections made and harnesses connected to the vehicle, turn ignition key to the ON position for thirty seconds, then turn key off.

(See Applications on back of page)

REV. 03/10/10 INSTXSVI-2003
1-800-221-0932 www.metraonline.com
METRA ELECTRONICS CORPORATION © COPYRIGHT 2010

XSVI-2003
INSTALLATION INSTRUCTIONS

In the GM vehicles listed below there are no 12 volt accessory wires currently in the factory harness making the installer run an accessory wire to the fuse box or underneath the steering column when installing an aftermarket radio. The XSVI-2003 is designed to provide a 12 volt 10 amp switched accessory output along with the rest of the wires needed to install an aftermarket radio. The R.A.P. (Retained Accessory Power) function, where power is supplied to the radio after the ignition is shut off until one of the front doors are opened, is retained by the XSVI-2003.

NOTE: The XSVI-2003 does not retain the factory warning chimes that are provided by the factory radio, Onstar, or the factory amplifier if so equipped.

Wiring the XSVI-2003:

Wiring up the XSVI-2003 is like wiring up any other wire harness that would attach to the aftermarket radios harness. The Metra/EIA wire code can be found on the back of this package that will aid you in the wiring of your aftermarket radio.

INITIALIZE THE XSVI INTERFACE BEFORE TURNING ON RADIO:

With all connections made and harnesses connected to the vehicle, turn ignition key to the ON position for thirty seconds, then turn key off.

(See Applications on back of page)

REV. 03/10/10 INSTXSVI-2003
1-800-221-0932 www.metraonline.com
METRA ELECTRONICS CORPORATION © COPYRIGHT 2010

XSVI-2003
INSTALLATION INSTRUCTIONS

In the GM vehicles listed below there are no 12 volt accessory wires currently in the factory harness making the installer run an accessory wire to the fuse box or underneath the steering column when installing an aftermarket radio. The XSVI-2003 is designed to provide a 12 volt 10 amp switched accessory output along with the rest of the wires needed to install an aftermarket radio. The R.A.P. (Retained Accessory Power) function, where power is supplied to the radio after the ignition is shut off until one of the front doors are opened, is retained by the XSVI-2003.

NOTE: The XSVI-2003 does not retain the factory warning chimes that are provided by the factory radio, Onstar, or the factory amplifier if so equipped.

Wiring the XSVI-2003:

Wiring up the XSVI-2003 is like wiring up any other wire harness that would attach to the aftermarket radios harness. The Metra/EIA wire code can be found on the back of this package that will aid you in the wiring of your aftermarket radio.

INITIALIZE THE XSVI INTERFACE BEFORE TURNING ON RADIO:

With all connections made and harnesses connected to the vehicle, turn ignition key to the ON position for thirty seconds, then turn key off.

(See Applications on back of page)

REV. 03/10/10 INSTXSVI-2003
1-800-221-0932 www.metraonline.com
METRA ELECTRONICS CORPORATION © COPYRIGHT 2010